


Thank you for purchasing our driving lamp conversion kit. If you have any questions, please call our technical support line at 740/622-9700. 

## Installation:

1. Completely loosen the screw on the terminal marked “H”.
2. Remove the wire on the terminal marked “P”.
3. Being careful not to stress the fragile diode assembly, install female spade connector found on diode assembly onto the terminal marked “P” while forked terminal slides under the head on the screw on the terminal marked “H”.
4. Tighten screw on “H” terminal and reinstall wire previously on “P” terminal onto the piggy-back terminal found on the diode assembly.

