


21546 Thank you for purchasing our reversible front door glass run. This door glass run is conveniently prepunched to accept your new rivets. This new style door glass run also has two different ends. Position the crimped end up for '56-'57 door pillars and the other end up for '55 model door pillars. Also we have included the rubber pad which is installed in the top of the door pillar casting. Questions? - Please call our tech-help line at 740/622-9700. 

Installing the rubber pad:

1. Remove the old pad (if it is still there) from the inside of the top of the casting.
2. Apply contact cement or weatherstrip adhesive to the rubber pad and the casting where the pad is installed.
3. Insert rubber pad firmly into place

Installing channel:

1. After removing old door glass run, thoroughly clean out channel.
2. Starting new glass run near the top of the door pillar casting, insert the new run firmly into the casting.
3. Slide run up against the rubber pad until the prepunched hole are aligned with the holes in the casting.
4. Insert new rivets (CASCO kit# 114) through the door glass run and then through the door pillar casting.
5. Put a piece of 1/4" wide steel or similar material into a vise and slide the door glass run and pillar casting assembly over it so that the head of the rivet is in contact with the steel.
6. Using a small hammer, lightly hammer the ends of the split rivet over.