

Swift Sure Brake Pedal Trim

***Note to resellers:** If resold, this trim piece (Part number 2454B2) must be advertised, priced, and boxed separately from all other brake components. Installation onto pedal assembly can only be performed by end user. - FoMoCo Corporate Trademark Licensing*

Installation instructions:

1. **Note: Be sure not to install trim upside down.** Before attaching trim piece to brake pedal, be sure that the pedal is right side up. The open side of mounting bracket on back of pedal faces up.
2. Hook one end of the trim piece under the stainless trim. As shown in figure 1.
3. Press trim piece into cavity along the length of pedal.
4. Double check that trim is not upside down!
5. Using a slotted screwdriver, snap the remaining end of trim under the outside trim ring by pressing into the rubber and then press down. See figure 2.

