

# 9600D & 9A659

## CAUTION

When installing this part be sure to check and double check the clearance between the top of the stud and the hood. This is important because many factors are involved in this clearance.

In our shop we check this clearance by putting a small amount of modelers clay on the stud and very carefully closing the hood. The clay will deform to indicate the clearance.

